

Oversized BB - Shimano Hollowtech II MTB Crank - Compatibility



**Shimano XTR
Triple Chainring**

Oversize BB Type	Adaptor Part #	Notes
BB30 w/ 68mm BB shell	Use BB30-Shim	Use Wheels Mfg. Part # BB30-SPC & Shimano supplied spacer
BB30 w/ 73mm BB shell	Use BB30-Shim	Use Wheels Mfg. Part # BB30-SPC & Shimano supplied spacer
Press Fit 30	No	Requires BB30 cranks
BB84.5 (Specialized MTB)	Use Shimano Part # SM-BB91-42A	Follow factory installation procedure
BB86 / BB91 (Giant / Scott)	No	
BB90 * (Trek)	No	* BB95 follows factory crank installation
BB92 * (Trek MTB)	Use Shimano Part # SM-BB91-41A	* BB95 follows factory crank installation



**Shimano MTB
Triple Chainring**

Oversize BB Type	Adaptor Part #	Notes
BB30 w/ 68mm BB shell	Use BB30-Shim	Use Wheels Mfg. Part # BB30-SPC
BB30 w/ 73mm BB shell	Use BB30-Shim	Use Wheels Mfg. Part # BB30-SPC
Press Fit 30	No	Requires BB30 cranks
BB84.5 (Specialized MTB)	Use Shimano Part # SM-BB91-42A	Follow factory installation procedure
BB86 / BB91 (Giant / Scott)	No	
BB90 * (Trek)	No	* BB95 follows factory crank installation
BB92 * (Trek MTB)	Use Shimano Part # SM-BB91-41A	* BB95 follows factory crank installation



**Shimano MTB
Double Chainring**

Oversize BB Type	Adaptor Part #	Notes
BB30 w/ 68mm BB shell	Use BB30-Shim	Use Wheels Mfg. Part # BB30-SPC
BB30 w/ 73mm BB shell	Use BB30-Shim	Use Wheels Mfg. Part # BB30-SPC
Press Fit 30	No	Requires BB30 cranks
BB84.5 (Specialized MTB)	Use Shimano Part # SM-BB91-42A	Follow factory installation procedure
BB86 / BB91 (Giant / Scott)	No	
BB90 * (Trek)	No	* BB95 follows factory crank installation
BB92 * (Trek MTB)	Use Shimano Part # SM-BB91-41A	* BB95 follows factory crank installation